

**Business and Mission-**

**Critical Solutions Provider** 

# PV Tracker Gateway PMM Tracking Solutions

## Data Sheet



Model: PMM1103G

Document: Data Sheet

Document version: 1.0

Date: October 2022



#### **COPYRIGHT NOTICE**

The information in this document is subject to change without prior notice to improve reliability, design, and function and does not represent a commitment on the part of the manufacturer.

In no event will the manufacturer be liable for direct, indirect, special, incidental, or consequential damage arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of the manufacturer.

#### **TRADEMARKS**

All registered trademarks and product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

AMI is a trademark of American Megatrends Inc.

Intel & Atom are trademarks of Intel Corporation

IBM, PC/AT, PS/2&VGA are trademarks of International Business Machines Corporation Microsoft Windows is a trademark of Microsoft Corp. RTL is the trademark of Realtek Semiconductor Co., Ltd.

#### **DECLARATION OF CONFORMITY**

This restriction is subject to protect the operational process of the system in the business environment, which will produce, use, and transmit radiofrequency energy. Harmful interference to radio communication could result if instructions to the correct installation and usage were not applied. The interference prevention cannot be guaranteed even with proper installation according to the manual. If the device causes a bad effect on the radio / TV signal. The user could preclude that by turning the device on/off.

When this device produces some harmful interference, the user can use the following measure to solve the interference problem:

- 1-Setting the receiving antenna's direction or location to increase the distance between this device and receiver.
- 2-Plug in the device's power connector into different circuits of the power outlet with the receiver.
- 3-If any technical support is needed, the dealer or experienced radio/TV technical personnel must be informed.

#### **TECHNICAL SUPPORT AND SERVICE**

Visit Pmm-usa.us to browse FAQs and get further details.

User should collect the following information before submitting technical support and service requests:

- Product name, model and serial number.
- Installed software (operating system, OS version, installed applications and so on).
- Full description of the problem
- -Detailed information about every error.

#### SAFETY INSTRUCTIONS

- Only trained and qualified personnel can install, operate, or maintain the device.
- Before starting the installation, all safety precautions must be read, and warning labels affixed to the device must be observed. Doing so protects the device from damage and ensures your
- Safety precautions provided in this document may not cover all safety aspects, note to always remain mindful of safety.
- PMM is not liable for any consequence that results from violation of regulations pertaining to safe operations or safety codes pertaining to design, production, and equipment usage.
- DO NOT use liquids or decontamination spray to clean the device surface and assure that it is totally disconnected while cleaning.
- Take all measures to prevent device drop before or during
- Prior to connecting the device to power source, ensure the source and device voltage and power are 100% matched.
- Keep the cables in a suitable covered place.
- If the device is not used for a long time, shut off the power to avoid the damages by transient overvoltage.
- DO NOT allow any liquid flow into the device; to avoid fire or short circuit.
- The recommended storage temperature range should NOT be less than 30°C OR higher than 85°C.



## Warning:

- Read the power source and device inlet carefully.
- Handle device with both hands.
- Clean and maintain the device using recommended, safe and suitable methods.



## Caution:

If any unauthorized changes of settings or repairs are done without PMM approval; then user's rights of controlling this device will be canceled.



## **Contents**

KEY FEATURES	4
DESCRIPTION	4
APPLICATIONS	
CONNECTION DIAGRAM	
TECHNICAL SPECIFICATIONS	
ENCLOSURE ASSEMBLY INFORMATION	
ENCLOSURE DIMENSIONS	8

#### **KEY FEATURES**

- Intelligence designed around high precision solar tracking needs
- Controlling up to two trackers simultaneously
- Compatible with any tracking system
- Built to meet all harsh environment and Power substation requirements
- Wide range of power supply options
- -40 to 85°C (-40 to 185°F) system operating temperature
- Compact size with fanless design
- Wide range of mounting options

#### **DESCRIPTION**

Tracker-mounted photovoltaic and solar thermal installations' efficiency and profitability greatly depend on how precisely the receiving units are directed at the sun; as a result, tracking control intelligence is essential to maximizing energy and profit return.

PMM1103G- gateway transmits the signal to the controller either through Modbus RS485, or Wi-Fi or LoRa then PMM1103 controller adjusts the angle of the trackers to the optimal angle which maximize the production. In addition, PMM1103G- receives signals from the position tracking sensor to be updated on cloud SCADA allowing for operator to easily monitor the tracker position through Web or mobile application.

Note: Refer to PMM1103C- Single Axis Tracker Controller for more details.


PMM1103 gateway is a rugged powerful reliable fanless Linux based embedded industrial computer, powered by Allwinner H3 CPU, which offers high-performance processing with a high degree of functional integration.

Moreover, PMM1103 gateway is covered by a durable metal chassis which was designed and tested on the field to withstand shock, vibration, extended temperature ranges and challenging elements of a harsh environment. It is especially designed to meet all power substations and PV plants requirements.

#### **APPLICATIONS**

- Single axis PV.
- Concentration PV (CPV).
- High-concentration PV (HCPV).
- Solar-thermal.
- Concentration solar-thermal.

#### **CONNECTION DIAGRAM**



**Note:** the connection between PMM1103 gateway and the controllers can be: Modbus RTU (2 wires), or Wi-Fi or LoRa.

## **TECHNICAL SPECIFICATIONS**

#### **Computer Interface**

Ethernet	2x 10/100Base-T RJ45
USB	1x USB2.0 Type A
	2x Micro USB
Wi-Fi	2.4 GHz
Serial	1x RS485
Optional Interface	16 pin connectors on edge with following connectivity options (max 3 options
	can be chosen upon order to be factory pre-fitted)
	RS232
	RS485
	RS422
	CAN bus
	Analogue Inputs
	Analogue Output
	Digital Inputs
	Digital Output
SD Slot	1x MicroSD card socket for user supplied card up to 64GB

#### **Power Parameters**

Power Supply Options	10-56 VDC
	8-40 VAC
	36-72 VDC
	25-50 VAC
	85-285 VAC / 100-300 VDC
Power Connector	Phoenix Contact 4pins 3.5mm

### **Physical Characteristics**

Housing	Metal				
Dimensions	4 x 4 x 1.75 inch (103 x 103 x 44 mm)				
Mounting Options	Standard 35mm DIN Rail Direct Panel Mounting Front Panel Mounting 19" rack 1U				
Certifications	RoHS, CE and FCC				


## **ENCLOSURE ASSEMBLY INFORMATION**




ITEM	DESCRIPTION
1	Screws
2	10x LED Indicators
3	Ethernet port
4	2x Communication Ports
5	2x Communication Ports
6	SD card slot
7	SD/mSIM card slot


8	2x Micro USB ports
9	Reset button
10	Heat Sink
11	Earth
12	DIP Switch
13	Power Adapter
14	USB Type A Port
15	Ethernet port


## **ENCLOSURE DIMENSIONS**





Top View














## **ORDERING INFORMATION**

Order Configuration table							
PMM1103 Gateway	-X	-09xx	-09xx	-09xx	Table1* Comm port options		
Power supply					<b>COM Ports Options</b>		
10-56 VDC	-1				Analog input	PMM0901	
8-40 VAC	-2	-			Analog output	PMM0902	
36-72 VDC	-3	-			CANBUS (UART)	PMM0910	
25-50 VAC	-4	-			CANBUS (UART)	PMM0910i	
85-285 VAC/100-300 VDC	-5				CANBUS (SPI)	PMM00911	
COM Port 1					CANBUS (SPI)	PMM0911i	
RS485		-0912			RS485	PMM0912	
CAN Bus		-0910			RS422	PMM0913	
ANALOG INPUTS		-0901			RS422	PMM0914	
DIGTAL INPUT		-0920			RS232	PMM0915	
GSM/GPRS		-0917			LTE	PMM0916	
See the COM Ports table for more options					Digital input	PMM0920	
COM Port 2 (Same as COM Port 1			-09xx		Digital output	PMM0921	
options <b>)</b>							
COM Port 3 (Same as COM Port 1&2 options)				-09xx			

#### Accessories

DIN Mount (included)	DIN Rail Mounting Bracket
Wall Mounting Kit (included)	2x Wall Mounting Bracket
Panel Mounting Kit(optional)	2x Panel Mounting Bracket
Rack Mounting Kit (optional)	Rack Mounting Bracket

## **CONTACT INFORMATION:**

For direct inquiries or any customized orders, contact us on <a href="mailto:sales@Pmm-usa.us">sales@Pmm-usa.us</a>